

Portweiterleitung mit einem *Allnet* Router

The screenshot shows the 'Virtual Servers' configuration page of an Allnet Router. On the left is a navigation menu with categories: ADVANCED SETTINGS (Access Control, Dynamic DNS, Internet, Virtual Servers, WAN Port), ADMINISTRATION (Config File, Log, Network Diag, Options, PC Database, Remote Admin, Routing, Security, Upgrade Firmware), and a bottom section. The 'Virtual Servers' option is selected. The main area is titled 'Virtual Servers' and contains a 'Servers' list with a dropdown menu showing 'Web', 'FTP(Control)', 'FTP(Data)', 'E-Mail(POP3)', and 'E-Mail(SMTP)'. There are 'Defaults', 'Disable All', and 'Delete' buttons. Below this is a 'Properties' section with a form. The 'Enable' checkbox is checked. The 'Server' dropdown is set to 'Web'. The 'PC (Server)' dropdown is set to 'Select a PC', with a link 'My PC is not listed'. The 'Protocol' dropdown is set to 'TCP'. The 'Internal (LAN) Ports' and 'External (WAN) Ports' are both set to '80'. There are 'Update Selected Server', 'Add as new Server', 'Clear Form', and 'Help' buttons.

Virtual Servers

Servers

Web
FTP(Control)
FTP(Data)
E-Mail(POP3)
E-Mail(SMTP)

Defaults
Disable All
Delete

Properties

☒ Enable Web

PC (Server): Select a PC My PC is not listed

Protocol: TCP

Internal (LAN) Ports: 80 ~ 80

External (WAN) Ports: 80 ~ 80

Clear Form

Update Selected Server Add as new Server

Help

1. Öffnen Sie den Browser und rufen Sie Ihren Router auf.
2. Klicken Sie auf *Administration*.
3. Gehen Sie zu *Virtual Services*.

Virtual Servers

Servers

Web
 FTP(Control)
 FTP(Data)
 E-Mail(POP3)
 E-Mail(SMTP)

Defaults
 Disable All
 Delete

Properties

☐ Enable Web

PC (Server): Select a PC My PC is not listed

Protocol: TCP

Internal (LAN) Ports: 80 ~ 80

External (WAN) Ports: 80 ~ 80

Clear Form

Update Selected Server Add as new Server

Help

4. *Servers*: Wählen Sie hier *Web* aus.
5. *Properties*: Setzen Sie den Haken bei *Enable* und tragen Sie einen frei wählbaren Namen ein.
6. *PC (Server)*: Wählen Sie hier das Gerät aus, dass Sie aus dem Internet erreichbar machen wollen.
7. *Protocol*: Wählen Sie hier TCP als Protokoll aus.
8. *Internal (LAN) Ports*: Wählen Sie hier den lokalen Port Ihres Gerätes (SSL Port: 443).
9. *External (WAN) Ports*: Wählen Sie hier einen öffentlichen Port den Sie freigeben wollen (frei wählbar, wir empfehlen einen 5-stelligen Port).
10. Klicken Sie dann auf *Add as new Server*.